



Quick Start Guide

VideoPoster-III (Standalone)

- Hardware connection
- Create a simply playlist via ACC-3 software
- Update a playlist via USB-Stick

Hardware Connection


Here you can find latest documentation.

<http://www.datadisplay-group.com/komponenten/industrielle-mediaplayer/videoposter-iii/>

- 1.) - Connect your cables from the Panel and Backlight Unit to your VideoPoster-III.
 - Insert the SD-Card AD-04-064 into the sd card slot (is required).
 - Insert the Lithium battery.
 - Power Up your VideoPoster-III Kit.

After about a half minute you will see a bootlogo and the player starts demo playlist.

Now you can go to step 2 an create your playlist and update it on the VideoPoster-III



Note:

Crossed HDMI port will work with firmware release 1.12 or upper.

Here you can find Firmware updates for the VideoPoster-III with releasenote and update documentation.


<http://www.datadisplay-group.com/service/downloads/mediaplayer-firmware/>



Create a simple playlist via ACC-3 Software

Here you can find the latest ACC-3 software
<http://www.datadisplay-group.com/service/downloads/artista-control-center/>

- 2.) This is a screenshot from first time running the ACC-3
Select **Type:** VideoPoster-III
Select Kit depend **Resolution:** example 1920x1080





- 4.) Insert USB-Stick PC-04-009 to your PC.



- 5.) Click on Export „Arrow“ to expand the Export selection and click Export to USB.

- 3.) Click on Add Icon and select some sample pictures




Finished

Here you have created a simple playlist for your VideoPoster-III with ACC-3 and export it to the USB Stick for further use.

Playlist update via USB-Stick

- 6.) – Please ensure the SD-Card is plugged in and the VideoPoster-III is powered up and is playing a playlist or showing the logo.
- Now insert the USB-Stick to upload the Playlist.
 - The VideoPoster-III gives you a status on the splash screen.
 - After the playlist was successfully updated you will be informed on the splash screen and after that USB-Stick has to be removed.



Finished

Now the VideoPoster-III is playing your playlist.

Our company network supports you worldwide with offices in Germany, Great Britain, the USA and Turkey.

For more information please contact:

Distec GmbH

Augsburger Str. 2b
82110 Germering

Germany

Phone: +49 (0)89 / 89 43 63-0
Fax: +49 (0)89 / 89 43 63-131
E-Mail: info@datadisplay-group.de
Internet: www.datadisplay-group.de

Display Technology Ltd.

5 The Oaks Business Village
Revenge Road, Lordswood
Chatham, Kent, ME5 8LF

United Kingdom

Phone: +44 (0)1634 / 67 27 55
Fax: +44 (0)1634 / 67 27 54
E-Mail: info@displaytechnology.co.uk
Internet: www.datadisplay-group.co.uk

Apollo Display Technologies, Corp.

87 Raynor Avenue, Unit 1
Ronkonkoma, NY 11779

United States of America

Phone: +1 631 / 580-43 60
Fax: +1 631 / 580-43 70
E-Mail: info@apolloDisplays.com
Internet: www.apolloDisplays.com



FORTEC Elektronik AG

Lechwiesenstr. 9
86899 Landsberg am Lech

Germany

Phone: +49 (0)8191 / 911 72-0
Fax: +49 (0)8191 / 217 70
E-Mail: sales@fortecag.de
Internet: www.fortecag.de

DATA DISPLAY GROUP

A **FORTEC** GROUP MEMBER

Sales Partner:

**DATA DISPLAY BİLİŞİM TEKNOLOJİLERİ
İÇ VE DIŞ TİCARET LİMİTED ŞİRKETİ**

Barbaros Mh Ak Zambak Sk A Blok D:143
TR-34376 Ataşehir/İstanbul

Turkey

Phone: +90 (0)216 / 688 04 68
Fax: +90 (0)216 / 688 04 69
E-Mail: info@data-display.com.tr
Internet: www.data-display.com.tr

your specialist for flat screen solutions