



OUR GLOBAL  
COMPETENCE  
CENTRES

 APOLLO DISPLAY  
TECHNOLOGIES



 DISTEC



 DISPLAY  
TECHNOLOGY




# Manual

## iBASE

### MI811

Mini-ITX Embedded Motherboard with Intel® Apollo Lake

Intel® Pentium®, Intel Celeron® Processors



---

The information contained in this document has been carefully researched and is, to the best of our knowledge, accurate. However, we assume no liability for any product failures or damages, immediate or consequential, resulting from the use of the information provided herein. Our products are not intended for use in systems in which failures of product could result in personal injury. All trademarks mentioned herein are property of their respective owners. All specifications are subject to change without notice.

---

# **MI811F Series**

**Intel® Pentium® & Celeron® SoC  
Mini-ITX Motherboard**

## **User's Manual**

Version 1.4  
(July 2020)

## **Copyright**

© 2020 IBASE Technology, Inc. All rights reserved.

No part of this publication may be reproduced, copied, stored in a retrieval system, translated into any language or transmitted in any form or by any means, electronic, mechanical, photocopying, or otherwise, without the prior written consent of IBASE Technology, Inc. (hereinafter referred to as "IBASE").

## **Disclaimer**

IBASE reserves the right to make changes and improvements to the products described in this document without prior notice. Every effort has been made to ensure the information in the document is correct; however, IBASE does not guarantee this document is error-free.

IBASE assumes no liability for incidental or consequential damages arising from misapplication or inability to use the product or the information contained herein, nor for any infringements of rights of third parties, which may result from its use.

## **Trademarks**

All the trademarks, registrations and brands mentioned herein are used for identification purposes only and may be trademarks and/or registered trademarks of their respective owners.

## Compliance



This product has passed CE tests for environmental specifications and limits. This product is in accordance with the directives of the European Union (EU). In a domestic environment, this product may cause radio interference in which case users may be required to take adequate measures.



This product has been tested and found to comply with the limits for a Class B device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with manufacturer's instructions, may cause harmful interference to radio communications.

## WEEE



This product must not be disposed of as normal household waste, in accordance with the EU directive of for waste electrical and electronic equipment (WEEE - 2012/19/EU). Instead, it should be disposed of by returning it to a municipal recycling collection point. Check local regulations for disposal of electronic products.

## Green IBASE



This product is compliant with the current RoHS restrictions and prohibits use of the following substances in concentrations exceeding 0.1% by weight (1000 ppm) except for cadmium, limited to 0.01% by weight (100 ppm).

- Lead (Pb)
- Mercury (Hg)
- Cadmium (Cd)
- Hexavalent chromium (Cr6+)
- Polybrominated biphenyls (PBB)
- Polybrominated diphenyl ether (PBDE)

## Important Safety Information

Carefully read the precautions before using the board.

### Environmental conditions:

- Use this product in environments with ambient temperatures between 0°C and 60°C.
- Do not leave this product in an environment where the storage temperature may be below -20° C or above 80° C. To prevent from damages, the product must be used in a controlled environment.

### Care for your iBASE products:

- Before cleaning the PCB, unplug all cables and remove the battery.
- Clean the PCB with a circuit board cleaner or degreaser, or use cotton swabs and alcohol.
- Vacuum the dust with a computer vacuum cleaner to prevent the fan from being clogged.



### WARNING

### Attention during use:

- Do not use this product near water.
- Do not spill water or any other liquids on this product.
- Do not place heavy objects on the top of this product.

### Anti-static precautions

- Wear an anti-static wrist strap to avoid electrostatic discharge.
- Place the PCB on an anti-static kit or mat.
- Hold the edges of PCB when handling.
- Touch the edges of non-metallic components of the product instead of the surface of the PCB.
- Ground yourself by touching a grounded conductor or a grounded bit of metal frequently to discharge any static.



### CAUTION

Danger of explosion if the internal lithium-ion battery is replaced by an incorrect type. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions or recycle them at a local recycling facility or battery collection point.

## Warranty Policy

- **IBASE standard products:**

24-month (2-year) warranty from the date of shipment. If the date of shipment cannot be ascertained, the product serial numbers can be used to determine the approximate shipping date.

- **3<sup>rd</sup>-party parts:**

12-month (1-year) warranty from delivery for the 3<sup>rd</sup>-party parts that are not manufactured by IBASE, such as CPU, CPU cooler, memory, storage devices, power adapter, panel and touchscreen.

- \* PRODUCTS, HOWEVER, THAT FAIL DUE TO MISUSE, ACCIDENT, IMPROPER INSTALLATION OR UNAUTHORIZED REPAIR SHALL BE TREATED AS OUT OF WARRANTY AND CUSTOMERS SHALL BE BILLED FOR REPAIR AND SHIPPING CHARGES.

## Technical Support & Services

1. Visit the IBASE website at [www.ibase.com.tw](http://www.ibase.com.tw) to find the latest information about the product.
2. If you need any further assistance from your distributor or sales representative, prepare the following information of your product and elaborate upon the problem.
  - Product model name
  - Product serial number
  - Detailed description of the problem
  - The error messages in text or in screenshots if there is any
  - The arrangement of the peripherals
  - Software in use (such as OS and application software, including the version numbers)
3. If repair service is required, you can download the RMA form at <http://www.ibase.com.tw/english/Supports/RMAService/>. Fill out the form and contact your distributor or sales representative.

# Table of Contents

---

<b>Compliance</b> .....	<b>iii</b>
<b>Important Safety Information</b> .....	<b>iv</b>
<b>Warranty Policy</b> .....	<b>v</b>
<b>Technical Support &amp; Services</b> .....	<b>v</b>
<b>Chapter 1      General Information</b> .....	<b>1</b>
1.1    Introduction .....	2
1.2    Features .....	2
1.3    Packing List .....	3
1.4    Optional Accessories .....	3
1.5    Specifications .....	4
1.6    Block Diagram .....	7
1.7    Overview .....	8
1.8    Dimensions .....	10
<b>Chapter 2      Hardware Configuration</b> .....	<b>11</b>
2.1    Essential Installations Before You Begin .....	12
2.1.1    Installing the Memory .....	12
2.2    Setting the Jumpers .....	13
2.3    Jumper & Connector Locations .....	14
2.4    Jumpers Quick Reference .....	16
2.4.1    LVDS Panel Power Selection (JP1) .....	16
2.4.2    Panel Output Selection (JP3) .....	17
2.4.3    Panel Backlight Control Selection (JP4) .....	18
2.4.4    ME Register Clearance (JP6) .....	19
2.4.5    CMOS Data Clearance (JP7) .....	20
2.4.6    eDP Backlight Power Selection (JP9) .....	21
2.4.7    eDP Panel Power Selection (JP10) .....	22
2.5    Connectors Quick Reference .....	23
2.5.1    eDP Connector (CN1) .....	24
2.5.2    COM1 RS-232/422/485 Port & COM2 RS-232 Port (CN2) ..	25
2.5.3    Dual USB 2.0 Port (CN3) .....	26
2.5.4    Dual USB 3.0 Port & LAN Port (CN4, CN5) .....	26
2.5.5    HDMI Port (CN6, CN7) .....	27



2.5.6	Audio Jack (CN10)	27
2.5.7	DVI-D Connector (J11)	28
2.5.8	SATA III Port (CN8, CN9)	29
2.5.9	Mini-PCIe Slot for mSATA (J8)	29
2.5.10	Mini-PCIe Slot (J7)	30
2.5.11	Panel Inverter Connector (J2)	30
2.5.12	LVDS Connector (J3, J4)	31
2.5.13	DC Power Input Connector (J6)	32
2.5.14	ATX Power Connector (J5)	33
2.5.15	Dual USB Port (J9, J23)	34
2.5.16	SATA Power Connector (J14, J15)	34
2.5.17	Front Panel Setting Connector (J12)	35
2.5.18	DDR3L SO-DIMM Slot (J10, J13)	36
2.5.19	Amplifier Connector (J16)	36
2.5.20	Audio Connector (J17)	37
2.5.21	COM3 & COM4 RS-232 Port (J18, J19)	38
2.5.22	Fan Connector (CPU_FAN1, SYS_FAN1)	38
2.5.23	Digital I/O Connector (J21)	39

## **Chapter 3 Drivers Installation ..... 41**

3.1	Introduction	42
3.2	Intel® Chipset Software Installation Utility	42
3.3	VGA Driver Installation	44
3.4	HD Audio Driver Installation	46
3.5	Intel® Trusted Execution Engine Drivers Installation	47
3.6	Intel® Serial IO Drivers Installation	49
3.7	LAN Drivers Installation	51

<b>Chapter 4</b>	<b>BIOS Setup.....</b>	<b>53</b>
4.1	Introduction .....	54
4.2	BIOS Setup .....	54
4.3	Main Settings .....	55
4.4	Advanced Settings .....	56
4.4.1	ACPI Computing .....	57
4.4.2	LVDS (eDP/DP) Configuration .....	58
4.4.3	iSmart Controller .....	59
4.4.4	Fintek Super IO Configuration .....	60
4.4.5	Fintek Super IO Hardware Monitor .....	62
4.4.6	CPU Configuration .....	63
4.4.7	AMI Graphic Output Protocol Policy .....	64
4.4.8	Network Stack Configuration .....	65
4.4.9	CSM Configuration .....	66
4.4.10	USB Configuration .....	67
4.5	Chipset Settings .....	68
4.5.1	South Cluster Configuration .....	68
4.6	Security Settings .....	73
4.7	Boot Settings.....	76
4.8	Save & Exit Settings.....	77
<b>Appendix</b>	<b>.....</b>	<b>79</b>
A.	I/O Port Address Map .....	80
B.	Interrupt Request Lines (IRQ).....	83
C.	Watchdog Timer Configuration.....	85

# Chapter 1

## General Information

The information provided in this chapter includes:

- Features
- Packing List
- Optional Accessories
- Specifications
- Block Diagram
- Board Overview
- Board Dimensions

## 1.1 Introduction

MI811F is a Mini-ITX motherboard based on the platform of Intel® Pentium® N4200 or Celeron® N3350. This board features HDMI at I/O coastline, on-board headers for eDP and 24-bit dual channel LVDS interfaces for video display. You can use either the eDP or LVDS interface. It operates at the ambient temperature ranging from 0°C to 60°C.



**Photo of MI811F**

## 1.2 Features

- Mini-ITX with Intel® Pentium® QC N4200 / Celeron® DC N3350 SoC
- 2 x DDR3L-1866 SO-DIMM socket, expandable up to 8GB
- 1 x HDMI, 1 x DVI-D (or 2<sup>nd</sup> HDMI), and eDP / 24-bit dual channel LVDS
- 2 x GbE LAN, 4 x USB 3.0, 6 x USB 2.0, 4 x COM, 2 x SATA III, 1 x PCIe (1x), 2 x Mini-PCIe slot
- Configurable watchdog timer and digital I/O

## 1.3 Packing List

Your MI811F package should include the items listed below. If any of the items below is missing, contact the distributor or dealer from whom you purchased the product.

- MI811F x 1
- IO Shield x 1
- SATA cable x 1  
(SATA-5 for ATX power connector;  
SATA-53 for DC-In power connector)
- COM cable (PK3K) x 1
- Disk x 1  
(including chipset drivers and flash memory utility)
- This User's Manual x 1

## 1.4 Optional Accessories

IBASE provides optional accessories as follows:

- Audio cable (Audio-18)
- USB 2.0 cable (USB29)

## 1.5 Specifications

<b>Product Name</b>	MI811F-420	MI811F-420D	MI811F-335	MI811F-335D
<b>Form Factor</b>	Mini-ITX Motherboard			
<b>System</b>				
<b>Operating System</b>	<ul style="list-style-type: none"> <li>Windows 10 Enterprise (64-bit)</li> <li>Windows 10 IoT Core (64-bit)</li> <li>Linux Ubuntu</li> </ul>			
<b>CPU Type</b>	Intel® Pentium® QC N4200		Intel® Celeron® DC N3350	
<b>CPU Speed</b>	1.1 ~ 2.5 GHz		1.1 ~ 2.4 GHz	
<b>Cache</b>	2 MB			
<b>Chipset</b>	Integrated			
<b>Memory</b>	2 x DDR3L-1866 SO-DIMM, expandable up to 8 GB (Non-ECC)			
<b>Storage</b>	mSATA SSD			
<b>Graphics</b>	Intel® Pentium® SoC integrated Gen. 9			
<b>Network</b>	2 x Intel® I211AT PCIe Gigabit Ethernet			
<b>Super I/O</b>	Fintek F81964D-I			
<b>Audio Codec &amp; Controller</b>	Intel® SoC built-in HD audio controller Realtek ALC283 codec with 2.1 channels and amplifier			
<b>Power Requirement</b>	ATX Power	DC-In 12 ~ 24V	ATX Power	DC-In 12 ~ 24V
<b>Watchdog Timer</b>	Yes (256 segments, 0, 1, 2...255 sec / min)			
<b>BIOS</b>	AMI BIOS			
<b>iSmart</b>	3.5			
<b>H/W Monitor</b>	Yes			
<b>Smart Control</b>	EuP/ErP wide temperature			


<b>Dimensions</b>	170 x 170 mm (6.7" x 6.7")
<b>RoHS</b>	Yes
<b>Certification</b>	CE, FCC Class B, LVD
<b>I/O Ports</b>	
<b>Display</b>	<ul style="list-style-type: none"> <li>• <b>1 x HDMI</b> (1.4b, CN7 connector), 3840 x 2160 at 30 Hz</li> <li>• <b>1 x HDMI</b> (1.4b, CN6 connector) or DVI-D, 3840 x 2160 at 30 Hz</li> <li>• <b>1 x eDP / 24-bit dual channel LVDS</b>  <b>eDP:</b> 4096 x 2160 at 60 Hz  <b>LVDS:</b> 1920 x 1200 at 60 Hz</li> </ul> <p>* If both the HDMI connector (CN6) and DVI-D connector (J11) ports are connected, HDMI will be given the precedence over DVI-D.</p> <p>* eDP and LVDS do not work at the same time.</p>
<b>LAN</b>	2 x RJ45 GbE LAN
<b>USB</b>	<ul style="list-style-type: none"> <li>• <b>4 x USB 3.0:</b> I/O coastline connectors</li> <li>• <b>6 x USB 2.0:</b> 2 ports at the I/O coastline 4 ports via on-board pin headers</li> </ul>
<b>Serial</b>	<p><b>4 x COM ports:</b></p> <ul style="list-style-type: none"> <li>• <b>COM1:</b> RS-232/422/485 (I/O coastline connector, jumperless selection)</li> <li>• <b>COM2:</b> RS-232 only (I/O coastline connector)</li> <li>• <b>COM3 &amp; COM4:</b> RS-232 only (via on-board box-headers)</li> </ul>
<b>SATA</b>	2 x SATA III (one is shared with the mini-PCIe slot (full-size) for mSATA)
<b>Audio</b>	<ul style="list-style-type: none"> <li>• Line-In</li> <li>• Line-Out</li> <li>• Microphone-Input</li> </ul>
<b>Digital IO</b>	4-In & 4-Out

<b>Expansion Slots</b>	<ul style="list-style-type: none"><li>• 1 x Mini PCIe slot (full-size) for mSATA</li><li>• 1 x Mini PCIe slot (half-size) with USB</li><li>• 1 x PCIe (x1) slot</li></ul>
<b>Environment</b>	
<b>Temperature</b>	<ul style="list-style-type: none"><li>• Operation: 0 ~ 60 °C (32 ~ 140 °F)</li><li>• Storage: -20 ~ 80 °C (-4 ~ 176 °F)</li></ul>
<b>Relative Humidity</b>	0 ~ 90 %, non-condensing at 60 °C

All specifications are subject to change without prior notice.



## 1.6 Block Diagram



## 1.7 Overview


### Top View



**Photo of MI811F (ATX power)**


\* The photos above are for reference only. Some minor components may differ.

**I/O View**



No.	Name	No.	Name
1	COM1 RS-232/422/485 Port	6	HDMI Port (given the precedence over the DVI-D connector, J11)
2	COM2 RS-232 Port	7	HDMI Port
3	USB 2.0 Port	8	Line-In
4	LAN Port (GbE)	9	Line-Out
5	USB 3.0 Port	10	Microphone-Input

### 1.8 Dimensions



## Chapter 2

# Hardware Configuration

This section provides information on jumper settings and connectors on the MI811F in order to set up a workable system. On top of that, you will also need to install crucial pieces such as the CPU and the memory before using the product. The topics covered are:


- Essential installations before you begin
- Jumper and connector locations
- Jumper settings and information of connectors

## 2.1 Essential Installations Before You Begin

Follow the instructions below to install the memory modules.

### 2.1.1 Installing the Memory

To install the modules, locate the memory slot on the board and perform the following steps:



1. Align the key of the memory module with that on the memory slot and insert the module slantwise.
2. Gently push the module in an upright position until the clips of the slot close to hold the module in place when the module touches the bottom of the slot.


To remove the module, press the clips outwards with both hands, and the module will pop-up.

## 2.2 Setting the Jumpers


Set up and configure your MI811F by using jumpers for various settings and features according to your needs and applications. Contact your supplier if you have doubts about the best configuration for your use.

### 2.2.1 How to Set Jumpers

Jumpers are short-length conductors consisting of several metal pins with a non-conductive base mounted on the circuit board. Jumper caps are used to have the functions and features enabled or disabled. If a jumper has 3 pins, you can connect either PIN1 to PIN2 or PIN2 to PIN3 by shorting.









A 3-pin jumper



A jumper cap


Refer to the illustration below to set jumpers.

Pin closed	Oblique view	illustration
Open		
1-2		
2-3		

When two pins of a jumper are encased in a jumper cap, this jumper is **closed**, i.e. turned **On**.

When a jumper cap is removed from two jumper pins, this jumper is **open**, i.e. turned **Off**.

## 2.3 Jumper & Connector Locations




Board diagram of MI811F

**Note:**

1. **J5** is only available for MI811F-420 & MI811F-335 (ATX power types).
2. **J6, J14, and J15** are only available for MI811F-420D & MI811F-335D (DC-In power types).






**Board diagram of MI811F**

## 2.4 Jumpers Quick Reference


Function	Jumper Name	Page
LVDS Panel Power Selection	JP1	16
Panel Output Selection	JP3	17
Panel Backlight Control Selection	JP4	18
ME Register Clearance	JP6	19
CMOS Data Clearance	JP7	20
eDP Backlight Power Selection	JP9	21
eDP Panel Power Selection	JP10	22
Factory Use Only	JP5	--



### 2.4.1 LVDS Panel Power Selection (JP1)




Function	Pin closed	Illustration
3.3V (default)	1-2	1
5V	2-3	1



### 2.4.2 Panel Output Selection (JP3)




Function	Pin closed	Illustration
eDP Panel	1-2	1 
LVDS Panel (default)	2-3	1 

### 2.4.3 Panel Backlight Control Selection (JP4)




Function	Pin closed	Illustration
3.3V (default)	Open	1 
5V	Close	1 

2.4.4 ME Register Clearance (JP6)




Function	Pin closed	Illustration
Normal (default)	1-2	1
Clear ME	2-3	1

## 2.4.5 CMOS Data Clearance (JP7)




Function	Pin closed	Illustration
Normal (default)	1-2	1
Clear CMOS	2-3	1



### 2.4.6 eDP Backlight Power Selection (JP9)



Function	Pin closed	Illustration
5V (default)	1-2	1
12V	2-3	1

## 2.4.7 eDP Panel Power Selection (JP10)




Function	Pin closed	Illustration
3.3V (default)	1-2	1 
5V	2-3	1 



## 2.5 Connectors Quick Reference


Function	Connector Name	Page
eDP Connector	CN1	24
COM1 RS-232/422/485 Port & COM2 RS-232 Port	CN2	25
Dual USB 2.0 Port	CN3	26
Dual USB 3.0 Port & LAN Port	CN4, CN5	26
HDMI Port	CN6 (shared with J11), CN7	27
Audio Jack	CN10	27
DVI-D Connector	J11 (shared with CN6)	28
SATA III Port	CN8, CN9	29
Mini-PCIe Slot for mSATA (full-size)	J8 (shared with CN8)	29
Mini-PCIe Slot (half-size)	J7	30
Panel Inverter Connector	J2	30
LVDS Panel Connector	J3 (Ch2), J4 (Ch1)	31
DC Power Input Connector	J6	32
ATX Power Connector	J5	33
Dual USB Connector	J9, J23	34
SATA Power Connector	J14, J15	34
Front Panel Setting Connector	J12	35
DDR3L SO-DIMM Slot	J10, J13	36
Amplifier Connector	J16	36
Audio Connector	J17	37
COM3 & COM4 RS-232 Port	J18 (COM4), J19 (COM3)	38
Fan Connector	CPU_FAN1, SYS_FAN1	38
Digital I/O Connector	J21	39
Factory Use Only	J1, J20, J22	--

## 2.5.1 eDP Connector (CN1)



Pin	Assignment	Pin	Assignment
1	N/A	16	Ground
2	BL_PWR	17	N/A
3	BL_PWR	18	VDD_eDP
4	BL_PWR	19	VDD_eDP
5	BL_PWR	20	Ground
6	N/A	21	AUX_N
7	N/A	22	AUX_P
8	Brightness	23	Ground
9	BKLT_EN	24	TX0_P
10	Ground	25	TX0_N
11	Ground	26	Ground
12	Ground	27	TX1_P
13	Ground	28	TX1_N
14	HPD	29	Ground
15	Ground	30	N/A

### 2.5.2 COM1 RS-232/422/485 Port & COM2 RS-232 Port (CN2)



COM1 RS-232/422/485 port is jumper-less and configurable in BIOS.


Pin	Assignment	Pin	Assignment
1	DCD, Data carrier detect	6	DSR, Data set ready
2	RXD, Receive data	7	RTS, Request to send
3	TXD, Transmit data	8	CTS, Clear to send
4	DTR, Data terminal ready	9	RI, Ring indicator
5	Ground		

Pin	Assignment		
	RS-232	RS-422	RS-485
1	DCD	TX-	Data-
2	RX	TX+	Data+
3	TX	RX+	NC
4	DTR	RX-	NC
5	Ground	Ground	Ground
6	DSR	NC	NC
7	RTS	NC	NC
8	CTS	NC	NC
9	RI	NC	NC


**COM2** RS-232 port:

Pin	Assignment	Pin	Assignment
1	DCD, Data carrier detect	6	DSR, Data set ready
2	RX, Receive	7	RTS, Request to send
3	TX, Transmit	8	CTS, Clear to send
4	DTR, Data terminal ready	9	RI, Ring indicator
5	Ground		

### 2.5.3 Dual USB 2.0 Port (CN3)




### 2.5.4 Dual USB 3.0 Port & LAN Port (CN4, CN5)




### 2.5.5 HDMI Port (CN6, CN7)


**CN6:** shared with J11  
(CN6 is the 1<sup>st</sup> priority.)



**CN7:**




### 2.5.6 Audio Jack (CN10)



## 2.5.7 DVI-D Connector (J11)


**J11:** shared with CN6  
(CN6 HDMI Port is the 1<sup>st</sup> priority.)




Pin	Assignment	Pin	Assignment
1	DATA1_P	2	DATA1_N
3	Ground	4	Ground
5	CLK_P	6	CLK_N
7	Ground	8	Ground
9	HPD	10	N/A
11	DATA2_P	12	DATA2_N
13	Ground	14	Ground
15	DATA0_P	16	DATA0_N
17	N/A	18	N/A
19	SDA	20	SCLK

## 2.5.8 SATA III Port (CN8, CN9)

**CN8:** shared with J8  
(CN8 is the 1<sup>st</sup> priority)




**CN9:**




## 2.5.9 Mini-PCIe Slot for mSATA (J8)


**J8** is shared with CN8.  
(CN8 SATA III Port is the 1<sup>st</sup> priority)



### 2.5.10 Mini-PCIe Slot (J7)




### 2.5.11 Panel Inverter Connector (J2)



Pin	Assignment	Pin	Assignment
1	+12V	3	BKLT_CTL
2	LVDS_BLON	4	Ground



## 2.5.12 LVDS Connector (J3, J4)




### J3:

Pin	Assignment	Pin	Assignment
1	LVS <sub>AE</sub> _P	2	LVS <sub>AE</sub> _N
3	Ground	4	Ground
5	LVS <sub>BE</sub> _P	6	LVS <sub>BE</sub> _N
7	Ground	8	Ground
9	LVS <sub>CE</sub> _P	10	LVS <sub>CE</sub> _N
11	Ground	12	Ground
13	LVS <sub>CKE</sub> _P	14	LVS <sub>CKE</sub> _N
15	Ground	16	Ground
17	LVS <sub>DE</sub> _P	18	LVS <sub>DE</sub> _N
19	VDD1	20	VDD1

**J4:**

Pin	Assignment	Pin	Assignment
1	LVSA0_P	2	LVSA0_N
3	Ground	4	Ground
5	LVSB0_P	6	LVSB0_N
7	Ground	8	Ground
9	LVSC0_P	10	LVSC0_N
11	Ground	12	Ground
13	LVSCK0_P	14	LVSCK0_N
15	Ground	16	Ground
17	LVSD0_P	18	LVSD0_N
19	VDD1	20	VDD1


### 2.5.13 DC Power Input Connector (J6)



**J6** is only available for MI811F-420D & MI811F-335D (DC-In types).

Pin	Assignment	Pin	Assignment
1	Ground	3	12 ~ 24V
2	Ground	4	12 ~ 24V


### 2.5.14 ATX Power Connector (J5)



**J5** is only available for MI811F-420 & MI811F-335 (ATX power types).


Pin	Assignment	Pin	Assignment
1	3.3V	11	3.3V
2	3.3V	12	-12V
3	Ground	13	Ground
4	+5V	14	PS-ON
5	Ground	15	Ground
6	+5V	16	Ground
7	Ground	17	Ground
8	Power good	18	-5V
9	5VSB	19	+5V
10	+12V	20	+5V

### 2.5.15 Dual USB Port (J9, J23)




Pin	Assignment	Pin	Assignment
1	+5V	2	Ground
3	USB0-	4	USB1+
5	USB0+	6	USB1-
7	Ground	8	+5V

### 2.5.16 SATA Power Connector (J14, J15)



Pin	Assignment	Pin	Assignment
1	+5V	3	Ground
2	Ground	4	+12V

### 2.5.17 Front Panel Setting Connector (J12)




Pin	Assignment	Pin	Assignment
1	Power BTN	2	Power BTN
3	HDD LED+	4	HDD LED-
5	Reset BTN	6	Reset BTN
7	Power LED+	8	Power LED-


**J12** is utilized for system indicators to provide light indication of the computer activities and switches to change the computer status. It provides interfaces for the following functions.

- ATX Power ON Switch (Pins 1 and 2)**  
 The 2 pins make an “ATX Power Supply On/Off Switch” for the system that connects to the power switch on the case. When pressed, the power switch will force the system to power on. When pressed again, it will power off the system.
- Hard Disk Drive LED Connector (Pins 3 and 4)**  
 This connector connects to the hard drive activity LED on control panel. This LED will flash when the HDD is being accessed.
- Reset Switch (Pins 5 and 6)**  
 The reset switch allows you to reset the system without turning the main power switch off and then on again. Orientation is not required when making a connection to this header.
- Power LED (Pins 7 and 8)**  
 This connector connects to the system power LED on control panel. This LED will light when the system turns on.

### 2.5.18 DDR3L SO-DIMM Slot (J10, J13)




### 2.5.19 Amplifier Connector (J16)




Pin	Assignment	Pin	Assignment
1	SPK-L+	3	SPK-R-
2	SPK-L-	4	SPK-R+

## 2.5.20 Audio Connector (J17)




Pin	Assignment	Pin	Assignment
1	HPOUT_L	2	HPOUT_R
3	HPOUT-JD	4	Ground
5	LINE2_L	6	LINE2_R
7	LINE1-JD	8	Ground
9	MIC_L	10	MIC_R
11	MIC1-JD	12	Ground

### 2.5.21 COM3 & COM4 RS-232 Port (J18, J19)




Pin	Assignment	Pin	Assignment
1	DCD, Data carrier detect	2	RXD, Receive data
3	TXD, Transmit data	4	DTR, Data terminal ready
5	Ground	6	DSR, Data set ready
7	RTS, Request to send	8	CTS, Clear to send
9	RI, Ring Indicator	10	Not used

### 2.5.22 Fan Connector (CPU\_FAN1, SYS\_FAN1)




Pin	Assignment	Pin	Assignment
1	Ground	3	Rotation detection
2	12V	4	Rotation Control





Pin	Assignment	Pin	Assignment
1	Ground	3	Rotation detection
2	12V		

### 2.5.23 Digital I/O Connector (J21)



Pin	Assignment	Pin	Assignment
1	Ground	2	VCC5
3	OUT3	4	OUT1
5	OUT2	6	OUT0
7	IN3	8	IN1
9	IN2	10	IN0

This page is intentionally left blank.

# Chapter 3

## Drivers Installation

This chapter introduces installation of the following drivers:

- Intel® Chipset Software Installation Utility
- VGA Driver
- HD Audio Driver
- Intel® Trusted Execution Engine Drivers
- Intel® Serial I/O Drivers
- LAN Drivers

### 3.1 Introduction

This section describes the installation procedures for software and drivers. The software and drivers are included with the motherboard. If you find anything missing, please contact the distributor where you made the purchase. The contents of this section include the following:

---

**Note:** After installing your Windows operating system, you must install the Intel® Chipset Software Installation Utility first before proceeding with the drivers installation.

---


### 3.2 Intel® Chipset Software Installation Utility

The Intel® Chipset drivers should be installed first before the software drivers to install INF files for Plug & Play function for Intel chipset components. Follow the instructions below to complete the installation.

1. Insert the disk enclosed in the package. Click **Intel** on the left pane and then **Intel(R) Chipset Software Installation Utility** on the right pane.



2. When the *Welcome* screen to the Intel® Chipset Device Software appears, click **Next** to continue.
3. Click **Yes** to accept the software license agreement.
4. On the *Readme File Information* screen, click **Install**.




5. When the driver has been completely installed, restart the computer for changes to take effect.

### 3.3 VGA Driver Installation


1. Click **Intel** on the left pane and then **Intel(R) Apollolake Graphics Driver** on the right pane.




2. When the *Welcome* screen appears, click **Next** to continue.



- Click **Yes** to accept the license agreement and click **Next** in the *Readme File Information* window.



- When setup is complete, click **Finish** to restart the computer for changes to take effect.




### 3.4 HD Audio Driver Installation

1. Click **Intel** on the left pane and then **Realtek High Definition Audio Driver** on the right pane.



2. On the *Welcome* screen of the InstallShield Wizard, click **Next**.



3. Click **Next** until the installation starts.
4. When the driver has been completely installed, restart the computer for changes to take effect.




### 3.5 Intel® Trusted Execution Engine Drivers Installation


1. Click **Intel** on the left pane and then **Intel(R) TXE Drivers** on the right pane.



2. When the *Welcome* screen appears, click **Next**.



3. Accept the license agreement and click **Next**.



4. When the driver has been successfully installed, restart the computer for changes to take effect.

## 3.6 Intel® Serial IO Drivers Installation


1. Click **Intel** on the left pane and then **Intel(R) Serial IO Drivers** on the right pane.




2. When the *Welcome* screen to the InstallShield Wizard appears, click **Next**.



3. Accept the license agreement and click **Next**.



4. In the *Readme File Information* window, click **Next** to continue. In the *Confirmation* window, click **Next** to start the installation process.



5. When the driver has been successfully installed, restart the computer for changes to take effect.

### 3.7 LAN Drivers Installation


1. Click **LAN Card** on the left pane and then **Intel LAN Controller Drivers** on the right pane.




2. Click **Intel(R) I21x Gigabit Network Drivers..**



- When the *Welcome* screen appears, click **Next**.



- Accept the license agreement and click **Next**.
- On the *Setup Options* screen, click the checkbox to select the desired driver(s) for installation. Then click **Next** to continue.



- The wizard is ready for installation. Click **Install**.
- When installation is completed, click **Finish** to restart the computer for changes to take effect.

# Chapter 4

## BIOS Setup

This chapter describes the different settings available in the AMI BIOS that comes with the board. The topics covered in this chapter are as follows:

- Main Settings
- Advanced Settings
- Chipset Settings
- Security Settings
- Boot Settings
- Save & Exit

## 4.1 Introduction

The BIOS (Basic Input/Output System) installed in the ROM of your computer system supports Intel® processors. The BIOS provides critical low-level support for standard devices such as disk drives, serial ports and parallel ports. It also provides password protection as well as special support for detailed fine-tuning of the chipset controlling the entire system.

## 4.2 BIOS Setup

The BIOS provides a Setup utility program for specifying the system configurations and settings. The BIOS ROM of the system stores the Setup utility. When you turn on the computer, the BIOS is immediately activated. Press the <Del> key immediately allows you to enter the Setup utility. If you are a little bit late pressing the <Del> key, POST (Power On Self Test) will continue with its test routines, thus preventing you from invoking the Setup.

If you still need to enter Setup, restart the system by pressing the "Reset" button or simultaneously pressing the <Ctrl>, <Alt> and <Delete> keys. You can also restart by turning the system Off and back On again.

The following message will appear on the screen:

```
Press <DEL> to Enter Setup
```

In general, press the arrow keys to highlight items, <Enter> to select, the <PgUp> and <PgDn> keys to change entries, <F1> for help, and <Esc> to quit.

When you enter the BIOS Setup utility, the *Main Menu* screen will appear on the screen. The Main Menu allows you to select from various setup functions and exit choices.

---

**Warning:** It is strongly recommended that you avoid making any changes to the chipset defaults.

These defaults have been carefully chosen by both AMI and your system manufacturer to provide the absolute maximum performance and reliability. Changing the defaults could make the system unstable and crash in some cases.

---




### 4.3 Main Settings




BIOS Setting	Description
System Date	Sets the date. Use the <Tab> key to switch between the data elements.
System Time	Set the time. Use the <Tab> key to switch between the data elements.

## 4.4 Advanced Settings

This section allows you to configure, improve your system and allows you to set up some system features according to your preference.




### 4.4.1 ACPI Computing




BIOS Setting	Description
Enable Hibernation	Enables / Disables the system ability to hibernate (OS/S4 Sleep State). This option may be not effective with some OS.
ACPI Sleep State	Selects an ACPI sleep state (Suspend Disabled or S3) where the system will enter when the Suspend button is pressed.

## 4.4.2 LVDS (eDP/DP) Configuration




BIOS Setting	Description
LVDS (eDP/DP) Support	Enables / Disables LVDS (eDP/DP)
Panel Color Depth	Selects a panel color depth as 18 or 24 (VESA or JEIDA) bit.
LVDS Channel Type	Sets the LVDS channel type as single or dual channel.
Panel Type	Selects a resolution that fits your panel. Options: 800 x 600 / 1024 x 768 / 1366 x 768 / 1440 x 900 / 1600 x 900 / 1280 x 1024 / 1920 x 1080
LVDS Backlight Level Control	Selects from Level 1 to Level 8 for the LVDS backlight.

## 4.4.3 iSmart Controller




BIOS Setting	Description
Power-On after Power failure	Enables / Disables the system to be turned on automatically after a power failure.
Schedule Slot 1 / 2	<p>Sets up the hour / minute for system power-on.</p> <p><b>Important:</b> If you would like to set up a schedule between adjacent days, configure two schedule slots.</p> <p>For example, if setting up a schedule from Wednesday 5 p.m. to Thursday 2 a.m., configure two schedule slots. But if setting up a schedule from 3 p.m to 5 p.m. on Wednesday, configure only a schedule slot.</p>

## 4.4.4 Fintek Super IO Configuration




BIOS Setting	Description
Standby Power on S5 (ERP)	Enables / Disables to provide the standby power for devices.  Options: All Enable / Enable Ethernet for WOL / All Disable
Serial Ports Configuration	Sets parameters of serial ports.  Enables / Disables the serial port and select an optimal setting for the Super IO device.

## 4.4.4.1. Serial Port 1 Configuration



BIOS Setting	Description
Serial Port	Enables / Disables the serial port.
Change Settings	<p>Selects an optimal settings for Super IO device.</p> <p>Options:</p> <ul style="list-style-type: none"> <li>• Auto</li> <li>• IO = 3F8h; IRQ = 4</li> <li>• IO = 3F8h; IRQ = 3, 4, 5, 6, 7, 9, 10, 11, 12</li> <li>• IO = 2F8h; IRQ = 3, 4, 5, 6, 7, 9, 10, 11, 12</li> <li>• IO = 3E8h; IRQ = 3, 4, 5, 6, 7, 9, 10, 11, 12</li> <li>• IO = 2E8h; IRQ = 3, 4, 5, 6, 7, 9, 10, 11, 12</li> </ul>
Device Mode	<p>Changes the serial port mode to:</p> <ul style="list-style-type: none"> <li>• RS232</li> <li>• RS485 TX Low Active</li> <li>• RS485 with Termination TX Low Active</li> <li>• RS422</li> <li>• RS422 with Termination</li> </ul>


## 4.4.5 Fintek Super IO Hardware Monitor



BIOS Setting	Description
CPU / System smart fan control	Enables / Disables the smart fan feature. Options: Disabled / 50 °C / 60 °C / 70 °C / 80 °C
Temperatures / Voltages	These fields are the parameters of the hardware monitoring function feature of the motherboard. The values are read-only values as monitored by the system and show the PC health status.
CPU Shutdown Temperature	Sets a threshold of temperature to shut down if CPU goes overheated. Options: Disabled / 70 °C / 75 °C / 80 °C / 85 °C / 90 °C / 95 °C




### 4.4.6 CPU Configuration




BIOS Setting	Description
Socket 0 CPU Information	Displays the socket specific CPU information.
CPU Power Management	Allows you to enable / disable Turbo Mode.
Active Processor Cores	Enables / Disables the cores in the processor package.
Monitor Mwait	Enables / Disables Monitor Mwait.

## 4.4.7 AMI Graphic Output Protocol Policy



BIOS Setting	Description
Output Select	Outputs interface

## 4.4.8 Network Stack Configuration



BIOS Setting	Description
Network Stack	Enables / Disables UEFI Network Stack.
IPv4 PXE Support	Enables / Disables IPv4 PXE Boot Support. If disabled, lpv4 PXE boot option will not be created.
IPv4 HTTP Support	Enables / Disables IPv4 HTTP Boot Support. If disabled, lpv4 HTTP boot option will not be created.
IPv6 PXE Support	Enables / Disables IPv6 PXE Boot Support. If disabled, lpv4 PXE boot option will not be created.
IPv6 HTTP Support	Enables / Disables IPv6 HTTP Boot Support. If disabled, lpv4 HTTP boot option will not be created.
PXE boot wait time	Assigns a period of time to press ESC key to abort the PXE boot.
Media detect count	Assigns a number of times to check the presence of media.

## 4.4.9 CSM Configuration




BIOS Setting	Description
CSM Support	Enables / Disables CSM support.
GateA20 Active	<ul style="list-style-type: none"> <li>• <b>Upon Request</b> disables GA20 when using BIOS services.</li> <li>• <b>Always</b> cannot disable GA20, but is useful when any RT code is executed above 1 MB.</li> </ul>
INT19 Trap Response	<p>Sets how BIOS reacts on INT19 trap by Option ROM.</p> <ul style="list-style-type: none"> <li>• <b>Immediate</b> executes the trap right away.</li> <li>• <b>Postponed</b> executes the trap during legacy boot.</li> </ul>
Boot option filter	Controls the priority of Legacy and UEFI ROMs.
Storage	Controls the execution of UEFI and Legacy Storage OpROM.
Video	Controls the execution of UEFI and Legacy Video OpROM.
Other PCI devices	Determines OpROM execution policy for devices other than network, storage or video.

## 4.4.10 USB Configuration




BIOS Setting	Description
Legacy USB Support	<ul style="list-style-type: none"> <li><b>Enabled</b> enables Legacy USB support.</li> <li><b>Auto</b> disables legacy support if there is no USB device connected.</li> <li><b>Disabled</b> keeps USB devices available only for EFI applications.</li> </ul>
XHCI Hand-off	This is a workaround for OSES without XHCI hand-off support. The XHCI ownership change should be claimed by XHCI driver.
USB Mass Storage Driver Support	Enables / Disables the support for USB mass storage driver.
USB Transfer time-out	The time-out value (1 / 5 / 10 / 20 secs) for Control, Bulk, and Interrupt transfers.
Device reset time-out	Gives seconds (10 / 20 / 30 / 40 secs) to delay execution of Start Unit command to USB mass storage device.
Device power-up delay	<p>The maximum time the device will take before it properly reports itself to the Host Controller.</p> <p><b>Auto</b> uses default value for a Root port it is 100ms. But for a Hub port, the delay is taken from Hub descriptor.</p>


## 4.5 Chipset Settings




### 4.5.1 South Cluster Configuration




## 4.5.1.1. HD Audio Configuration



## 4.5.1.2. PCI Express Configuration




BIOS Setting	Description
PCI Express Root Port 1 ~ 6	Accesses the control of the PCI Express Root Port.



BIOS Setting	Description
PCI Express Root Port	Enables/ Disables the PCIe root port. <b>Auto:</b> To disable unused root port automatically for the most optimum power savings.
ASPM	Sets the PCIe active state power management. Options: Disable, L0s, L1, L0SL1, Auto
L1 Substates	Sets PCIe L1 substates. Options: Disabled, L1.1, L1.2, L1.1 & L1.2
PME SCI	Enables / Disables PME SCI.
PCIe Speed	Configures the PCIe speed. Options: Auto, Gen1, Gen2




### 4.5.1.3. SATA Drivers




BIOS Setting	Description
Chipset SATA	Enables / Disables the Chipset SATA Controller. The Chipset SATA Controller supports the 2 black internal SATA ports (up to 3Gb/s supported per port).
SATA Mode Selection	Determines how SATA controller(s) operate.

#### 4.5.1.4. USB Configuration




BIOS Setting	Description
XHCI Pre-Boot Driver	Enables / Disables the support for XHCI Pre-Boot Driver.
XHCI Mode	Enables / Disables XHCI mode. If disabled, XHCI controller would be disabled, and none of the USB devices are detectable or usable when system is booted up in OS. Do NOT disable it unless for debug purpose.
USB VBUS	VBUS should be ON in HOST mode. It should be OFF in OTG device mode.
USB HSIC1 Support	Enables / Disables USB HSIC1.
USB SSIC1 Support	Enables / Disables USB SSIC1.
USB Port Disable Override	Selectively enables / disables the corresponding USB port from reporting a device connection to the controller.
XDCI Support	Enables / Disables XDCI.
XHCI Disable Compliance Mode	<b>FALSE</b> makes the XHCI Link Compliance Mode not disabled. <b>TRUE</b> disables the XHCI Link Compliance Mode.


## 4.6 Security Settings



BIOS Setting	Description
Setup Administrator Password	Sets an administrator password for the setup utility.
User Password	Sets a user password.
Secure Boot	Customizable Secure Boot settings




BIOS Setting	Description
Secure Boot	Secure Boot activated when: Secure Boot is enabled Platform Key (PK) is enrolled, System mode is User/Deployed and CSM is disabled.
Secure Boot Customization	Secure Boot Mode – Custom & Standard, Set UEFI Secure Boot Mode to STANDARD mode or CUSTOM mode, this change is effect after save. And after reset, the mode will return to STANDARD mode.
Restore Factory Keys	Force System to User Mode. Configure NVRAM to contain OEM-defined factory default Secure Boot keys
Reset to Setup Mode	Provision factory default keys on next re-boot only when System in Setup mode
Key Management	Enables expert users to modify Secure Boot Policy variables without full authentication



BIOS Setting	Description
Factory Key Provision	Provision factory default keys on next re-boot only when System in Setup Mode
Restore Factory Keys	Force System to User Mode. Configure NVRAM to contain OEM-defined factory default Secure Boot Keys
Enroll Efi Image	Allow the image to run in Secure Boot mode. Enrol SHA256 Hash certificate of a PE image into Authorized Signature Database (db)
Restore DB defaults	Restore DB variable to factory defaults
Platform Key (PK)	<p>Enroll Factory Defaults or load certificates from a file:</p> <ol style="list-style-type: none"> <li>Public Key Certificate in:               <ol style="list-style-type: none"> <li>EFI_SIGNATURE_LIST</li> <li>EFI_CERT_X509 (DER encoded)</li> <li>EFI_CERT_RSA2048 (bin)</li> <li>EFI_CERT_SHA256, 384, 512</li> </ol> </li> <li>Authenticated UEFI Variable</li> <li>EFI PE/COFF Image (SHA256)</li> </ol> <p>Key Source: Factory, External, Mixed</p>

## 4.7 Boot Settings



BIOS Setting	Description
Setup Prompt Timeout	Number of seconds to wait for setup activation key. 65535 (0xFFFF) means indefinite waiting.
Bootup NumLock State	Selects the keyboard NumLock state.
Quiet Boot	Enables / Disables Quiet Boot option.
New Boot Option Policy	Controls the placement of newly detected UEFI boot options. Options: Default, Place First, Place Last
Boot mode select	Selects a Boot mode, Legacy / UEFI / Dual.
Boot Option Priorities	Sets the system boot order priorities for hard disk, CD/DVD, USB, Network.

## 4.8 Save & Exit Settings



BIOS Setting	Description
Save Changes and Exit	Exits system setup after saving the changes.
Discard Changes and Exit	Exits system setup without saving any changes.
Save Changes and Reset	Resets the system after saving the changes.
Discard Changes and Reset	Resets system setup without saving any changes.
Save Changes	Saves changes done so far to any of the setup options.
Discard Changes	Discards changes done so far to any of the setup options.
Restore Defaults	Restores / Loads defaults values for all the setup options.
Save as User Defaults	Saves the changes done so far as User Defaults.
Restore User Defaults	Restores the user defaults to all the setup options.

This page is intentionally left blank.



# Appendix

This section provides the mapping addresses of peripheral devices and the sample code of watchdog timer configuration.

## A. I/O Port Address Map

Each peripheral device in the system is assigned a set of I/O port addresses which also becomes the identity of the device. The following table lists the I/O port addresses used.

Address	Device Description
0x00000A00-0x00000A0F	Motherboard resources
0x00000A10-0x00000A1F	Motherboard resources
0x00000A20-0x00000A2F	Motherboard resources
0x0000002E-0x0000002F	Motherboard resources
0x0000004E-0x0000004F	Motherboard resources
0x00000061-0x00000061	Motherboard resources
0x00000063-0x00000063	Motherboard resources
0x00000065-0x00000065	Motherboard resources
0x00000067-0x00000067	Motherboard resources
0x00000070-0x00000070	Motherboard resources
0x00000070-0x00000070	System CMOS/real time clock
0x00000080-0x0000008F	Motherboard resources
0x00000092-0x00000092	Motherboard resources
0x000000B2-0x000000B3	Motherboard resources
0x00000680-0x0000069F	Motherboard resources
0x00000400-0x0000047F	Motherboard resources
0x00000500-0x000005FE	Motherboard resources
0x00000600-0x0000061F	Motherboard resources
0x0000164E-0x0000164F	Motherboard resources
0x0000F040-0x0000F05F	Intel(R) Celeron(R)/Pentium(R) Processor SMBUS - 5AD4
0x0000D000-0x0000DFFF	Intel(R) Celeron(R)/Pentium(R) Processor PCI Express Root Port - 5AD9

Address	Device Description
0x000003F8-0x000003FF	Communications Port (COM1)
0x000002F8-0x000002FF	Communications Port (COM2)
0x000003E8-0x000003EF	Communications Port (COM3)
0x000002E8-0x000002EF	Communications Port (COM4)
0x0000E000-0x0000EFFF	Intel(R) Celeron(R)/Pentium(R) Processor PCI Express Root Port - 5AD8
0x00000000-0x0000006F	PCI Express Root Complex
0x00000078-0x00000CF7	PCI Express Root Complex
0x00000D00-0x0000FFFF	PCI Express Root Complex
0x00000020-0x00000021	Programmable interrupt controller
0x00000024-0x00000025	Programmable interrupt controller
0x00000028-0x00000029	Programmable interrupt controller
0x0000002C-0x0000002D	Programmable interrupt controller
0x00000030-0x00000031	Programmable interrupt controller
0x00000034-0x00000035	Programmable interrupt controller
0x00000038-0x00000039	Programmable interrupt controller
0x0000003C-0x0000003D	Programmable interrupt controller
0x000000A0-0x000000A1	Programmable interrupt controller
0x000000A4-0x000000A5	Programmable interrupt controller
0x000000A8-0x000000A9	Programmable interrupt controller
0x000000AC-0x000000AD	Programmable interrupt controller
0x000000B0-0x000000B1	Programmable interrupt controller
0x000000B4-0x000000B5	Programmable interrupt controller
0x000000B8-0x000000B9	Programmable interrupt controller
0x000000BC-0x000000BD	Programmable interrupt controller
0x000004D0-0x000004D1	Programmable interrupt controller
0x0000F000-0x0000F03F	Intel(R) HD Graphics

<b>Address</b>	<b>Device Description</b>
0x0000F090-0x0000F097	Standard SATA AHCI Controller
0x0000F080-0x0000F083	Standard SATA AHCI Controller
0x0000F060-0x0000F07F	Standard SATA AHCI Controller
0x00000040-0x00000043	System timer
0x00000050-0x00000053	System timer

## B. Interrupt Request Lines (IRQ)

Peripheral devices use interrupt request lines to notify CPU for the service required. The following table shows the IRQ used by the devices on board.

Level	Function
IRQ 0	System timer
IRQ 3	Communications Port (COM2)
IRQ 4	Communications Port (COM1)
IRQ 4	PCI Data Acquisition and Signal Processing Controller
IRQ 5	Communications Port (COM3)
IRQ 5	PCI Data Acquisition and Signal Processing Controller
IRQ 6	PCI Data Acquisition and Signal Processing Controller
IRQ 7	PCI Data Acquisition and Signal Processing Controller
IRQ 8	High precision event timer
IRQ 10	Communications Port (COM4)
IRQ 14	Intel(R) Serial IO GPIO Host Controller - INT3452
IRQ 25	High Definition Audio Controller
IRQ 35	PCI Data Acquisition and Signal Processing Controller
IRQ 36	PCI Data Acquisition and Signal Processing Controller
IRQ 37	PCI Data Acquisition and Signal Processing Controller
IRQ 39	SDA Standard Compliant SD Host Controller
IRQ 54 ~ IRQ 204	Microsoft ACPI-Compliant System
IRQ 256 ~ IRQ 511	Microsoft ACPI-Compliant System
IRQ 4294967279	Intel(R) USB 3.0 eXtensible Host Controller - 1.0 (Microsoft)

<b>Level</b>	<b>Function</b>
IRQ 4294967280 ~ IRQ 4294967285	Intel(R) I211 Gigabit Network Connection #2
IRQ 4294967286 ~ IRQ 4294967291	Intel(R) I211 Gigabit Network Connection
IRQ 4294967292	Intel(R) Trusted Execution Engine Interface
IRQ 4294967293	Intel(R) HD Graphics
IRQ 4294967294	Standard SATA AHCI Controller

## C. Watchdog Timer Configuration

The Watchdog Timer (WDT) is used to generate a variety of output signals after a user programmable count. The WDT is suitable for use in the prevention of system lock-up, such as when software becomes trapped in a deadlock. Under these sorts of circumstances, the timer will count to zero and the selected outputs will be driven.

Under normal circumstance, you will need to restart the WDT at regular intervals before the timer counts to zero.

### Sample Code:

```
//-----
//
// THIS CODE AND INFORMATION IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY
// KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE
// IMPLIED WARRANTIES OF MERCHANTABILITY AND/OR FITNESS FOR A PARTICULAR
// PURPOSE.
//
//-----
#include <dos.h>
#include <conio.h>
#include <stdio.h>
#include <stdlib.h>
#include "F81866.H"
//-----
int main (int argc, char*argv[]);
void EnableWDT(int);
void DisableWDT(void);
//-----
int main (int argc, char *argv[])
{
    unsigned char bBuf;
    unsigned char bTime;
    char **endptr;

    char SIO;

    printf("Fintek 81866 watch dog program\n");
    SIO = Init_F81866();
    if (SIO == 0)
    {
        printf("Can not detect Fintek 81866, program abort.\n");
        return(1);
    }
    //if (SIO == 0)

    if (argc != 2)
    {
        printf("Parameter incorrect!!\n");
        return (1);
    }
}
```

```

bTime = strtol( argv[1], endptr, 10);
printf("System will reset after %d seconds\n", bTime);

if (bTime)
{
    EnableWDT(bTime);
}
else
{
    DisableWDT();
}
return 0;
}
//-----
void EnableWDT(int interval)
{
    unsigned char bBuf;

    bBuf = Get_F81866_Reg(0x2B);
    bBuf &= (~0x20);
    Set_F81866_Reg(0x2B, bBuf);           //Enable WDTO

    Set_F81866_LD(0x07);                 //switch to logic device 7
    Set_F81866_Reg(0x30, 0x01);         //enable timer

    bBuf = Get_F81866_Reg(0xF5);
    bBuf &= (~0x0F);
    bBuf |= 0x52;
    Set_F81866_Reg(0xF5, bBuf);         //count mode is second

    Set_F81866_Reg(0xF6, interval);     //set timer

    bBuf = Get_F81866_Reg(0xFA);
    bBuf |= 0x01;
    Set_F81866_Reg(0xFA, bBuf);         //enable WDTO output

    bBuf = Get_F81866_Reg(0xF5);
    bBuf |= 0x20;
    Set_F81866_Reg(0xF5, bBuf);         //start counting
}
//-----
void DisableWDT(void)
{
    unsigned char bBuf;

    Set_F81866_LD(0x07);                 //switch to logic device 7

    bBuf = Get_F81866_Reg(0xFA);
    bBuf &= ~0x01;
    Set_F81866_Reg(0xFA, bBuf);         //disable WDTO output

    bBuf = Get_F81866_Reg(0xF5);
    bBuf &= ~0x20;
    bBuf |= 0x40;
    Set_F81866_Reg(0xF5, bBuf);         //disable WDT
}
//-----
//-----

```



```

//
// THIS CODE AND INFORMATION IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY
// KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE
// IMPLIED WARRANTIES OF MERCHANTABILITY AND/OR FITNESS FOR A PARTICULAR
// PURPOSE.
//
//-----
#include "F81866.H"
#include <dos.h>
//-----
unsigned int F81866_BASE;
void Unlock_F81866 (void);
void Lock_F81866 (void);
//-----
unsigned int Init_F81866(void)
{
    unsigned int result;
    unsigned char ucDid;

    F81866_BASE = 0x4E;
    result = F81866_BASE;

    ucDid = Get_F81866_Reg(0x20);
    if (ucDid == 0x07) //Fintek 81866
    {
        goto Init_Finish;
    }

    F81866_BASE = 0x2E;
    result = F81866_BASE;

    ucDid = Get_F81866_Reg(0x20);
    if (ucDid == 0x07) //Fintek 81866
    {
        goto Init_Finish;
    }

    F81866_BASE = 0x00;
    result = F81866_BASE;

Init_Finish:
    return (result);
}
//-----
void Unlock_F81866 (void)
{
    outputb(F81866_INDEX_PORT, F81866_UNLOCK);
    outputb(F81866_INDEX_PORT, F81866_UNLOCK);
}
//-----
void Lock_F81866 (void)
{
    outputb(F81866_INDEX_PORT, F81866_LOCK);
}
//-----
void Set_F81866_LD( unsigned char LD)
{
    Unlock_F81866();
    outputb(F81866_INDEX_PORT, F81866_REG_LD);
    outputb(F81866_DATA_PORT, LD);
    Lock_F81866();
}

```

```

}
//-----
void Set_F81866_Reg( unsigned char REG, unsigned char DATA)
{
    Unlock_F81866();
    outputb(F81866_INDEX_PORT, REG);
    outputb(F81866_DATA_PORT, DATA);
    Lock_F81866();
}
//-----
unsigned char Get_F81866_Reg(unsigned char REG)
{
    unsigned char Result;
    Unlock_F81866();
    outputb(F81866_INDEX_PORT, REG);
    Result = inportb(F81866_DATA_PORT);
    Lock_F81866();
    return Result;
}
//-----

//-----
//
// THIS CODE AND INFORMATION IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY
// KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE
// IMPLIED WARRANTIES OF MERCHANTABILITY AND/OR FITNESS FOR A PARTICULAR
// PURPOSE.
//
//-----
#ifndef F81866_H
#define F81866_H                1
//-----
#define F81866_INDEX_PORT      (F81866_BASE)
#define F81866_DATA_PORT      (F81866_BASE+1)
//-----
#define F81866_REG_LD          0x07
//-----
#define F81866_UNLOCK          0x87
#define F81866_LOCK            0xAA
//-----
unsigned int Init_F81866(void);
void Set_F81866_LD( unsigned char);
void Set_F81866_Reg( unsigned char,
unsigned char); unsigned char
Get_F81866_Reg( unsigned char);
//-----
#endif // F81866_H

```

Our company network supports you worldwide with offices in Germany, Austria, Switzerland, the UK and the USA. For more information please contact:

## Headquarters

### Germany



#### FORTEC Elektronik AG

Augsburger Str. 2b  
82110 Germering

Phone: +49 89 894450-0  
E-Mail: [info@fortecag.de](mailto:info@fortecag.de)  
Internet: [www.fortecag.de](http://www.fortecag.de)

## Fortec Group Members

### Austria



#### Distec GmbH Office Vienna

Nuschinggasse 12  
1230 Wien

Phone: +43 1 8673492-0  
E-Mail: [info@distec.de](mailto:info@distec.de)  
Internet: [www.distec.de](http://www.distec.de)

### Germany



#### Distec GmbH

Augsburger Str. 2b  
82110 Germering

Phone: +49 89 894363-0  
E-Mail: [info@distec.de](mailto:info@distec.de)  
Internet: [www.distec.de](http://www.distec.de)

### Switzerland



#### ALTRAC AG

Bahnhofstraße 3  
5436 Würenlos

Phone: +41 44 7446111  
E-Mail: [info@altrac.ch](mailto:info@altrac.ch)  
Internet: [www.altrac.ch](http://www.altrac.ch)

### United Kingdom



#### Display Technology Ltd.

Osprey House, 1 Osprey Court  
Hichingbrooke Business Park  
Huntingdon, Cambridgeshire, PE29 6FN

Phone: +44 1480 411600  
E-Mail: [info@displaytechnology.co.uk](mailto:info@displaytechnology.co.uk)  
Internet: [www.displaytechnology.co.uk](http://www.displaytechnology.co.uk)

### USA



#### Apollo Display Technologies, Corp.

87 Raynor Avenue,  
Unit 1 Ronkonkoma,  
NY 11779

Phone: +1 631 5804360  
E-Mail: [info@apolloDisplays.com](mailto:info@apolloDisplays.com)  
Internet: [www.apolloDisplays.com](http://www.apolloDisplays.com)